

# Tilting Microwave Detector (314, 314B)

The 314 Tilting Microwave Detector provides occupancy detection for the automatic control of DALI lighting loads.

The unit detects movement using its highly sensitive microwave detector. It emits low-power microwave signals and measures the reflections as the signals bounce off moving objects. The adjustable sensor head allows the area of detection to be optimised for the required application.

This product is compatible with Helvar's lighting system design and control software: Designer, and Toolbox. It can also be controlled using a Helvar infrared remote handset.

The unit can be mounted into a ceiling or wall void, or onto a solid surface using Helvar's SBB-A or SBB-AB back boxes (available separately).

From hardware revision 4, the Tilting Microwave Detector can be used with a Helvar 401, 402 or 403 or a generic 12 V to 24 V power supply unit.




## Key Features

- The microwave sensor detects movement within the detection range allowing load control in response to changes in room occupancy.
- The IR receiver receives control and programming commands from a Helvar infrared remote handset (available separately).
- The Status LEDs flash red to indicate the following:


Valid setting received	
Identify Active	

= Red LED

## Detection Pattern



Detector head position at 80° to the vertical for large offices or classrooms, and for corridor and aisles. Sensitivity set to maximum.



Detector head position at 0° to the vertical for open plan areas and offices. Sensitivity set to maximum.

## Technical Data

### Connections

**External power / DALI:** Removable terminal block  
Wire section: 0.5 mm<sup>2</sup> – 1.5 mm<sup>2</sup>  
solid or stranded

**Cable rating:** All cables must be mains rated.

### Power

**DALI supply input:** 13 V to 22.5 V

**DALI consumption:** 40 mA  
Note: DALI consumption is less than 2 mA when external power is supplied to the unit.

**(Optional) External power:** 12 V to 24 V; 0.5 W

### Remote control functions

**Use Helvar infrared remote handset to:** Recall lighting scenes 1–4.  
– Adjust light levels.  
– Store current level.  
– Install preset levels for scenes 1–4.  
Note: Adjust sensitivity using Designer, or Toolbox (not by remote control unit).  
Factory setting for sensor sensitivity: 9 (maximum).

### Microwave operating frequency

Model	Frequency
314	10.687 GHz China, Hong Kong, India, Malaysia, Middle East, Singapore, United Kingdom
314/R2	10.525 GHz Australia, Europe except for Austria, France, Germany, Ireland, Portugal, Slovakia, Switzerland and the United Kingdom
314/R3	9.900 GHz France, Portugal, Switzerland

### Mechanical data

**Mounting hole diameter:** 78 mm

**Bezel diameter:** 85 mm

**Recommended clearance depth (incl. 50 mm for cabling):** 80 mm (without protective cover)  
100 mm (with protective cover)

**Material (casing):** Flame retardant ABS and PC/ABS

**Finish / Colour:** **314:** Matt / White RAL 9003  
**314B:** Matt/ Anthracite Grey RAL 7016

**Weight:** 124 g

**IP code:** IP30

### Operating conditions

**Ambient temperature:** 0 °C to +50 °C

**Relative humidity:** Max. 90 %, noncondensing

**Storage temperature:** –10 °C to +70 °C

### Conformity and standards

**EMC immunity:** EN 61000-6-1

**EMC emission:** EN 61000-6-3

**Safety:** EN 60730-1

**Environment:** Complies with WEEE and RoHS directives.

### Version information

**Software version:** 6

**Hardware version:** Rev. 4

### Software compatibility

**Designer:** 4.1 or later

**Toolbox:** 2.2.16 or later

### Dimensions (mm)

